



WARRANTY CARD

© 2014 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All rights reserved.
Distributed by Jarden Consumer Solutions of India Private Limited, Unit B-204, Universal Business
Park, Off Saki Vihar Road, Chandivali Farm Road, Andheri (E) Mumbai 400 072, India. 2 Year
Limited Warranty - see inside for details. Sunbeam Products, Inc. and Jarden Consumer Solutions
of India Private Limited are subsidiaries of Jarden Corporation (NYSE: JAH).
1-800-102-6300

www.oster.in

Model No. : _____

Date of Purchase : _____

Dealer's Stamp : _____

Printed in PRC

P.N. 9100200001353
CKSTMC950-049_14EM1
GCDS-OST35455-SL



MODELS **CKSTMC950-049**

INSTRUCTION MANUAL
MINI CAKE MAKER

READ AND SAVE ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

IMPORTANT SAFEGUARDS

When using an electrical appliance basic safety precautions should always be followed including the following:

1. Read carefully and save all the instructions provided with an appliance. This appliance is not a toy.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electric shock do not immerse cord, plugs or any part in water or other liquid.
4. Always plug your appliance cord into a power outlet of the voltage (A.C. only) marked on the appliance.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Close supervision is necessary when your appliance is being used by children.
7. Never leave an appliance unattended while in use.
8. Do not use an appliance for any purpose other than its intended use.
9. Do not place an appliance on or near a hot gas flame, electric element or on a heated oven. Do not place on top of any other appliance.
10. Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
11. Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner.
12. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
13. Do not use outdoors.
14. Appliances are not intended to be operated by means of an external timer or separate remote control system.
15. This appliance is intended for household use only.
16. Operate the Mini Cake Maker on a flat surface.
17. Do not place any part of this appliance in a dishwasher.
18. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

SAVE THESE INSTRUCTIONS

DESCRIPTION OF THE APPLIANCE



- a Power light indicator
- b Ready light indicator
- c Upper housing
- d Upper cooking plate

- e Bottom cooking plate
- f Bottom housing
- g Lid Latch

OPERATING INSTRUCTIONS

For mini cake batter you can use:

1. Store bought cake mix.
2. Use the mini cake recipes beginning on page 7 or a store bought cake mix.

Before initial use:

1. Remove all packaging.
2. Clean the baking surfaces with a soft damp cloth, then dry it.
3. Unwind the power cord completely.
4. Wash cooking surfaces with hot sudsy water and a soft sponge.

NEVER IMMERSE COOKING SURFACES IN WATER.

To use Mini Cake Maker follow these guidelines:

1. Insert the plug into appropriate standard power outlet. Power Light indicator will turn on.
2. Allow your Mini Cake Maker to pre-heat until the 'READY' light comes on. This indicates that the cooking plates have reached the correct temperature for cooking.
3. When your Mini Cake Maker is heated for the first time it may emit slight smoke or odor, this is normal with heating appliances. This does not affect the safety of your appliance.

Tip: When placing mixture into the Mini Cake Maker, it is advised to lightly spray the cooking plates with a cooking oil spray before use. Fill bottom cavities well with batter. Do not overfill.

4. Gently close the lid and make sure lid latch is engaged.
5. Allow to cook until a tooth pick inserted into the mini cake comes out clean.

Tip: Do not lift the lid before the recommended cooking time as this will affect the result.

6. To remove mini cakes, always use a plastic or wooden spatula. Never use a sharp object or metal, as this will damage the non-stick surface of the cooking plates.

NOTE: SURFACES ARE HOT. UNPLUG FROM OUTLET WHEN NOT IN USE AND BEFORE CLEANING.

CARE AND CLEANING

This appliance should be cleaned after every use.

1. Always unplug Mini Cake Maker from outlet when not in use or before cleaning. Allow to completely cool before cleaning. The cooking plates are coated with non-stick cooking surface, therefore little cleaning is required. Simply wipe cooking plates over with a damp cloth.
2. Do not immerse the Mini Cake Maker in water or other liquids. Do not use abrasive scouring pads, powders or cleaners. Before next use; lightly grease the cooking plates for easy removal of cooked mini cakes.
3. Do not wash in dishwasher.

HELPFUL HINTS

1. Cooking times may vary depending on the mini cake batter mixture.
2. Cake mixes are suitable to use in the Mini Cake Maker. Use the recipe and method as directed on the packet mix but only cook until a toothpick inserted into the mini cake comes out clean.
3. Do not open the Mini Cake Maker before the recommended cooking time as this can affect the cooking result of the mini cakes.
4. Finished mini cakes can be frozen and thawed for later use. Allow the mini cakes to cool completely then place into an airtight container and freeze. Mini cakes can be individually wrapped and frozen for lunchbox treats.
5. Use a flat rounded knife or angled spatula to spread icing easily. Angled spatulas are available from kitchen supply stores.

RECIPES

Vanilla Mini Cakes

- 1 cup flour
- $\frac{2}{3}$ cup sugar
- 1 $\frac{1}{4}$ teaspoons baking powder
- $\frac{1}{4}$ teaspoon salt
- $\frac{1}{3}$ cup melted butter
- $\frac{1}{2}$ cup milk
- 1 egg, lightly beaten
- 1 teaspoon vanilla extract

Lightly spray Mini Cake Maker inside on top and bottom with non-stick cooking spray. Close lid, plug in and preheat Mini Cake Maker until bake ready light turns on. Combine flour, sugar, baking powder and salt. In another bowl, combine butter, milk, egg and vanilla. Pour wet ingredients into dry ingredients and stir until just fully incorporated. Fill well and close lid. Do not overfill. Cook until lightly browned. Remove mini cakes, let cool and top with your favorite frosting.

Chocolate Brownie Mini Cakes

- $\frac{1}{2}$ cup (1 stick) butter
- $\frac{1}{4}$ cup bittersweet or semisweet chocolate morsels
- 2 tablespoons cocoa powder
- $\frac{3}{4}$ cup sugar
- $\frac{1}{4}$ teaspoon salt
- 2 large eggs, lightly beaten
- $\frac{1}{2}$ cup flour

Lightly spray Mini Cake Maker inside on top and bottom with non-stick cooking spray. Close lid, plug in and preheat Mini Cake Maker until bake ready light turns on. Melt butter and chocolate in microwave for 25 seconds, stir, and repeat until butter and chocolate are just melted. Stir to combine. In a medium bowl combine cocoa, sugar, salt and eggs and stir well. Pour in chocolate and butter mixture; stir well until just fully incorporated. Stir in flour. Fill well and close lid. Do not overfill. Cook until a toothpick inserted into mini cake comes out clean. Remove mini cakes, let cool and top with ganache or chocolate frosting/filling.

NOTE: Fill bottom cavities well with batter.

RECIPES

Breakfast Corn and Bacon Mini Cakes

- $\frac{1}{2}$ cup cornmeal
- $\frac{1}{3}$ cup flour
- 1 tablespoon sugar
- 1 $\frac{1}{2}$ teaspoons baking powder
- $\frac{1}{4}$ teaspoon Kosher salt
- $\frac{2}{3}$ cup milk
- 1 large egg, lightly beaten
- 2 tablespoons butter, melted
- $\frac{1}{4}$ cup cooked, crumbled bacon

Lightly spray Mini Cake Maker inside on top and bottom with non-stick cooking spray. Close lid, plug in and preheat Mini Cake Maker until bake ready light turns on. In medium bowl, combine cornmeal, flour, sugar, baking powder and salt. In a small bowl, combine milk, egg and butter. Pour wet ingredients into dry ingredients, add bacon and stir until just fully incorporated. Fill well and close lid. Do not overfill. Cook until a toothpick inserted into the mini cake comes out clean. Remove food and serve.

NOTE: For best results, fill batter to top of bottom cavity.

WARRANTY

Jarden Consumer Solutions of India Private Limited (hereinafter referred to as "JCS") warrants that, for a period of two (2) years from the date of purchase of this product as evidenced in the cash memo ("Warranty Period"), this product will be free from defects in material and workmanship (the "Warranty"). Please preserve the warranty card and the cash memo of the product duly stamped and signed by the dealer, as this will be required for any claims under this Warranty.

- The rights and benefits under this Warranty are additional to your statutory rights, which are not affected by this Warranty.
- During the Warranty Period, JCS, at its sole choice, will either repair or replace this product or any component of the product found to be defective free of cost through (the dealer from whom the product was purchased or through the service center listed in the card – business people to confirm), provided that:
 - JCS is promptly informed of the defect;
 - The product has not been altered in any way or subjected to misuse or repair by the person other than a person authorized by JCS;
 - This Warranty, duly filled, stamped and signed by the dealer is made available.
- The Warranty provided herein is towards the original purchaser and is not transferrable to any third party.
- Any repaired or replaced product will be warranted on these terms for the remaining portion of the Warranty in the country where the product was purchased.
- Liability for consequential loss or damage is neither accepted nor is it implied.
- This Warranty is in lieu of all others expressed or implied and does not cover the following:
 - a. If product was use in any manner other than the intended use.
 - b. If the product has not been used according to the instruction manual/user's manual, included with the product.
 - c. If the defects are caused by improper use or reckless use.
 - d. If the product was altered or repaired by anyone other than those authorized by JCS.
 - e. If installation of the product is not done as per the printed instructions provided along with the product.
 - f. If the defects are caused by fire, flood, and other act of god.
 - g. If the defects are caused by use of incorrect current or voltage or faulty electric power supply.
 - h. Normal wear and tear of parts and accessories resulting from regular use.
 - i. Damage resulting from transportation, accidents, mishandling or negligence on the part of the consumer.
 - j. The following part/components:
 - Broken glass or ceramic parts
 - Light bulb
 - Accessories
 - k. If the product is put to industrial or commercial use.
 - JCS will not be responsible for any delay in servicing due to non-availability of any components or due to reasons beyond the control of JCS.
 - Any failure of the product to perform any purpose other than the intended purpose shall not be considered as a default under this warranty.
 - In any event, if JCS becomes liable for damages incurred in connection with these presents, then the liability of JCS will be limited to the amount equal to the sale invoice amount paid by you.

Waste electrical products should not be disposed off with household waste. Please recycle where facilities exist.

AUTHORIZED SERVICE CENTERS

Region	State	City	Name	Address	Contact Person	Contact No.
East	West Bengal	Kolkata	Jeeves Consumer Services Pvt Ltd	356, Jodhpur Park, Kolkata - 700068	Someswar Basu	(033) 40012100
	West Bengal	Kolkata	Southern Service	6/19A, Prince Anwarshah Road, Poddar Nagar, Kolkata - 700068	Subrata Manna	(033) 24729651 / 65488822
	West Bengal	Kolkata	Baishanu Service Care	55D, Adaya Nath Saha Road, Lake Town, Near Jaya Cinema, Kolkata - 700048	Piyush Nandan	(033) 40664210
	West Bengal	Howrah	Time n Service	37 & 38, Mohenath Lane, Salkia, Howrah - 711106	Tapas Hazra	(033) 65639720
	West Bengal	Hooghly	DNP Enterprises	52, Sahaganj Main Road, P.O. Sahaganj, Near Bandel Station, Hooghly - 712104	Indrajit Bag	(0) 9163668360
	West Bengal	Barrackpore	Balaji Enterprise	4/E/A Barasat Road, Barrackpore, Dist. North 24 Parganas, Near 15 No. Rail Gate, Barrackpore - 700122	Pradip Kr Ghosh	(033) 25451224
	West Bengal	Siliguri	S D Electronics	Deys Lodge, 138/69/57, Nazrul Sarani, Ashrampara, Siliguri - 734001	Arup Dey	(0353) 2526028
	West Bengal	Asanol	Yes Service	Hutton Road, Near Mahal Banquet Marriage Hall, Asanol - 713301	Sarfraz Ahmed	(03228) 2280029
	Assam	Guwahati	Multi Track Services	G S Road, Ground Floor, Bora Service Station, Ulubari, Guwahati - 781007	Kallol Dutta	(0361) 2457296

AUTHORIZED SERVICE CENTERS

North	Delhi	Delhi	Jeeves Consumer Services Pvt Ltd.	# E-10, Arya Samaj Road, School Road, Uttam Nagar, Delhi - 1100059	Md Khalid Pervez	(011) 45785915
	Delhi	Delhi	Jeeves Consumer Services Pvt Ltd.	R-32, 2nd Floor, Vikas Marg, Shakarpur, Opp. Heera Sweets, Metro Pillar # 46, Delhi - 1100092	Manjeet Singh	(011) 47754764
	Delhi	Delhi	S T Services	M-131, 1st Floor, Guru Harkrishan Nagar, Paschim Vihar, New Delhi - 110041	Vipin Yadav	(011) 32958438 / 45586987
	Haryana	Gurgaon	Jeeves Consumer Services Pvt Ltd.	4/18 A, 1st Floor, Laxmi Garden, Behind Police Chowki, Khandas Road, Gurgaon-122001	Karamvir Fogaat	(0124) 4073434
	Haryana	Faridabad	Jeeves Consumer Services Pvt Ltd.	5H-49, 1st Floor, NIT Faridabad -121001	Manoj Kumar Panwar	(0129) 4163003
	Uttar Pradesh	Noida	Jeeves Consumer Services Pvt Ltd.	1st Floor, Above Punjab ATM, Sector-22, Chaura More Main Road, Near Oriental Bank of Commerce, Opp.Rajkiya Inter College, Noida, U.P - 201301	Devender Singh	(0120) 4162644
	Uttar Pradesh	Lucknow	Swastik Customer Care	A-1/3, SEC-H Aliganj, Near Kendriya Bhawan, Lucknow - 226020	Uma Shankar Mishra	(0522) 3298003 / 4102581 / 4102582
	Uttar Pradesh	Kanpur	Shubham Electronics	192, Manohar Nagar Barra -3, Opp Deepshika Guest House, Kanpur - 208027	Suman Gupta	(0512) 2283394 / 2602029
	Uttar Pradesh	Agra	Sai Electronics	25/113, Gandhi Nagar, Agra - 282 003	Ajay Singhal / Sunil	(0562) 3297005
	Haryana	Ambala	Telecare	Old Hospital Road, Bara Thakur Dwar, Opp. Polytechnic, Ambala City - 134003	Devinder Sharma	(0171) 25567369
	Haryana	Sonapat	Saibaba Enterprises	House No. 1510, Sector - 15, Sonapat - 131001	Pramod Sharma	(0130) 6411206
	Haryana	Karnal	Jeeves Consumer Services Pvt Ltd.	Shop # 50, Ground Floor, Mayapuri, Rajiv Gandhi Marg/ Near Raj Palace, Meeraghati Chowk, Karnal - 132001	Neeraj Sharma	(0184) 4022201
	Punjab	Mohali	Jeeves Consumer Services Pvt Ltd.	# SCF-4, Basement, The High Land Society, NAV, Baltana, Zirakhpur, Mohali-140603	Shiv Dhanda	(0176) 2652574
	Punjab	Ludhiana	Jeeves Consumer Services Pvt Ltd.	Shop # 18B, Dhyani Singh Commercial Complex, Opp. Bus Stand, Ludhiana - 141001	Gurbeer Singh	(0161) 2444002
	Punjab	Jalandhar	Jeeves Consumer Services Pvt Ltd.	EH-31, Laddowali Road, Opposite Gurudwara, Jalandhar - 144001	Ashok Kumar	(0181) 2221707
	Punjab	Amritsar	Keerat Electronics	Naraingarh Bazar, Shaheed Bhagat Singh Road, Chheharta, Amritsar - 143 001	Sukhdeep / Mantreet Singh	(0183) 2450095
	Himachal	Shimla	Suvidha Electronics	Mehta Niwas, Ground Floor, Near Himfard Building, B C S, New Shimla - 171009	Rajesh Kumar	(0) 9816457886
	Himachal	Mandi	Kuldeep Electro Care	Near FCI Godown, Kehanwal Road, Ram Nagar, Mandi - 175001	Kuldeep Singh	(01905) 222140 / 329574
	Rajasthan	Jaipur	Jeeves Consumer Services Pvt Ltd.	A-79, Subash Nagar Shopping Centre, Jaipur - 302016	Vipendra Singh	(0141) 4035102

AUTHORIZED SERVICE CENTERS

West	Maharashtra	Mumbai	S P Services	Shop No. 10, Abdul Sattar Compound, Fitwala Road, Opp. Satguru Darshan Bldg., Near Railway Station, Elphinstone Road (West), Mumbai - 400013	Palsingh Panyari	(022) 24326726 / 24312623
	Maharashtra	Mumbai	Jeeves Consumer Services Pvt Ltd.	Plot No 27/5, Pawani Chowk, Opp Mulund Darshan Building, Mulund Colony, Mulund (W), Mumbai - 400082	Ramesh Yadav	(022) 65288597
	Maharashtra	Mumbai	Jeeves Consumer Services Pvt Ltd.	Shop No.1-1A, Ground floor, Kirti Co-Op Housing Society, Ramachandra Extn Lane, Near Movie Time, Evershine Nagar, Malad(W), Mumbai-400064	Murali Joshi	(022) 65278590
	Maharashtra	Pune	Jeeves Consumer Services Pvt Ltd.	No. 337, Sai Leela, 1st Floor, Datt Wadi, Mhasoba Chowk, Pune - 411030	Saket Dubey	(020) 24321679
	Maharashtra	Nagpur	Technic Services	Khare Building, Hanuman Lane, Sitabuli, Nagpur - 440 012	Dilip Panda	(0712) 2550076
	Maharashtra	Chandrapur	Suvidha Electronics	No. 1, Devt Appartment, Church Road, Hanuman Nagartukum, Chandrapur - 442401	Subash Deashkar	(07172) 258966 / 256453
	Maharashtra	Kolhapur	Sikir Mobiles	1492 C Ward, Laxmipuri, Opp. TATA Brand Stores, Kolhapur - 416001	Sukir Bakare	(0) 9372555011
	Maharashtra	Aurangabad	Emperor Services	S-5, Manik Arcade Kalda Corner, Opp Chowbey Hospital, Chetna Nagar, Aurangabad -31005	Mr. Willy Bento Colaco	(0240) 2350606
	Maharashtra	Nashik	Harsha Electronics	3, Talak Complex, Rachna Vidyalaya Road, Sharanpur Roda, Nashik - 422002	Pravin Patil	(0) 9422254240
	Goa	Salcete	Jolly Enterprises	Shop # G-2, 78/A Nuvem Enclave, Along NH-17 Highway, Belloy Nuvem, Salcete - 403604	John Gonzanalves	(0832) 2791800
	Gujarat	Ahmedabad	Jeeves Consumer Services Pvt Ltd.	No. 37, Om Tower, Near Star Bazar, Jodhpur Cross Road, Satellite, Ahmedabad - 380015	Girish Parmar	(079) 40080485
	Gujarat	Baroda	Uday Refrigeration	G/3 Nandanvan Complex, Atma Jyoti Ashram Road, Behind Citizen Society, Ellora Park, Baroda	Shailesh	(0265) 6590948
	Gujarat	Surat	Sadgurudev	Shop No. L/6, Shankutal Complex, Beside Sangvi Tower, Near Gujarat Gas Circle, Adajan Patia, Surat - 395009	Manoj Rana	(0261) 6540417
	Gujarat	Rajkot	PC Systems	4-Sardar Nagar (West), Tagore Road, Near Astron Circle, Rajkot-360001	Manoj Gohil	(0281) 2480479
	Madhya Pradesh	Indore	Cool Home Refrigeration	LG-70, Trade Centre, 18, South Tukogunj, Indore- 452 001	Husain Anjum	(0731) 4076404
	Madhya Pradesh	Bhopal	Jeeves Consumer Services Pvt Ltd.	Ward no 47, Goyal Vihar, Ground floor, Flat no-G-1, 31-C, Zone-2, MP Nagar, Bhopal	Ram Ashish Prasad	(0755) 4059310

AUTHORIZED SERVICE CENTERS

South	Tamil Nadu	Chennai	Jeeves Consumer Services Pvt Ltd.	New No.3,Old No.1-A, Sripuram,2nd Lane,Royapetah, Chennai-600014	Dinesh Kumar	044-42632371
	Tamil Nadu	Chennai	G C Services	Old No. 12, New No. 37, 1st Floor, Sattanna Naichen Street, Nehru Timber Market, Choolai, Chennai - 600112	Naval R	(044) 26690084 / 42822868
	Tamil Nadu	Coimbatore	V K Engineering	108-A/92, West Ponnurangam Road, Ground Floor (Near Telephone Exchange), R.S.Puram, Coimbatore - 641002	Selvadurai	(0422) 2541172
	Pondicherry	Pondicherry	Bestronics	49, Saint Theresa Street, Pondicherry - 605001	B Jayashankar	(0) 9443728020
	Andhra Pradesh	Hyderabad	Jeeves Consumer Services Pvt Ltd.	Flat No. 205, Karan Centre, Opp. IBP Petrol Pump and Karan Hotel, Park Lane, S.D.Road, Near Paradise Circle, Secunderabad - 500003	Kumararajan	(040) 64591168
	Andhra Pradesh	Vijaywada	Jeeves Consumer Services Pvt Ltd.	Door No.25-10-10A,G.S.Raju Road,Gandhi Nagar, Near Gymkhana Road, Vijayawada - 520003	Rahamatullah Gouse Khan	(0866) 6591168
	Karnataka	Bangalore	Jeeves Consumer Services Pvt Ltd.	No. 126, 1st Floor, 8th Main J.P.Nagar, 3rd Phase, Bangalore - 560078	Ramesh Kumar	(080) 41209331
	Karnataka	Bangalore	Jeeves Consumer Services Pvt Ltd.	First Floor, Khan Bldg. 7 & 8th Cross, Jakkasandra Extension, Bangalore - 560032	Surulivel	(080) 25520424
	Karnataka	Mangalore	Jeeves Consumer Services Pvt Ltd.	1st Floor, Quadra compound, Bejai,kapikad, Kavoor Road, Mangalore -575004	Divakar Shetty	(0824) 2213699
	Karnataka	Mysore	Jeeves Consumer Services Pvt Ltd.	No.1095, 1st Floor, C&D Block, Lalithadri Road, Kuvempunagar, Mysore - 570023	Venkatesh.S.Kulkarni	(0821) 4191094

NOTES